

COMECTA Sealer "305-C"

FEATURES

Sealer for any type of thermo-plastic material up to 0.4 mm thickness.

Easy to use: Pressure and release.

Manual cutting by slip cutting edge.

Energy saving system by a micro-switch, activated only when the sealing arm is in place.

Heat impulse for only 0.2 to 1.3 seconds.

Time controll according to the thickness of plastics to be seal.

A LED and audible beep are activated when the seal is complete.



MODEL

Part No.	Seal Width mm	Maximum seal length mm	Maximum plastic thickness mm	Seal time seconds	Height / Width / Depth (exterior) cm	Power W	Weight Kg
5800042	5	300	0.4	of 0.2 to 1.3	19 48 8.2	1100	5.2

Supplied complete with 2 heaters, 2 PTFE heater covers and cutting blade.

ADDITIONAL SPARES: Maintenance kit 305-C: 2 heaters, 2 PTFE heater covers and cutting blade Part No. **5800044**